

PHOENIX 3

1. Throttle ~~Old- S31009*~~

New- S12-034-00300

*** Stock is gone use new style.**

2. Handgrip- S31003

3. Upper Tiller Cover For
Digital Battery Gauge- S31004GT
Horn Button- S31012

4. Key Switch- S31006
Key- S3KEY

5. Headlight- S31022
Headlight Switch- S31122

6. Speed Dial- S31001
Speed Dial Knob- LRM412103-11

7. Battery Gauge
Analog- S31208
Digital- S31208B

8. Charger Port- S31147

9. Basket Mount- BC35051

10. Tiller Swivel Assembly- S350109
Tiller Adjustment Knob- S31028

11. Tiller Bearing Set- S31021

12. Fork Cover- S350127

13. Tension Knob- S350169715

14. T Handle Frame Lock- S350169716

15. Seat Pin- S350169717

16. Main Shroud Decoration (subs)
Blue Left- S3501BL
Right- S3501BR **[1] [2]**
Red Left- S3501RL
Right- S3501RR

17. Main Shroud- S350110

18. Controller Cover- S350113

19. Foot Shroud- S350114

20. Battery Pack- S350169707
Case Only- S350169706


21. Battery Contact- S31060

22. Battery (2 needed)- LRM402109

23. Charger- LRM302111

24. Controller- S31008GT

25. Rear Wheel- S31132B



[1] When stock is gone the part is no longer available.

01/14/2021

Diagrams

Home