

PILOT 2410


Only parts listed below are available.

1. PC Board Gen 1- LRA402204
Gen 2- **Stock is gone use**
Gen 3 PC board and LRA402204-03SD

PC Board Gen 3- LRA402204-03
Speed Dial- LRA402204-03SD
Speed Dial Knob- LRM412103-11
Horn- LRM402200-21

2. Key- LRB402323-01
Key Switch- LRB402323-02
3. Throttle- LRA402202
Throttle Spring- LRA402206-02
4. Basket- LRA402226
Basket Linner- LRA402206-FBL
5. Basket Bracket- LRM412101-08
6. Tiller Adjusting Knob- LRA402201-23
7. Shroud Knob- LDR410115-03
8. Seat Assembly 18"- ST301-181820-S
Seat 20"- ST301-201820
Seat Assembly 20"- ST301-201820-S
(assembly includes seat, arms, slide & bracket)
9. Armrest Pad Bolt On- LDR410110
10. Armrest Assembly Left (slide on)- **NLA** use LDR410011L
Right (slide on)- **NLA** use LDR410011R
Armrest Assembly Left (bolt on)- LDR410011L
Right (bolt on)- LDR410011R
(assembly include arm & pad)
Armrest Knob Height- LDR410011-12
Width- LDR410011-11

11. Front Wheel Bearing- STDS2A5303
12. Rear Wheel Gray- LDR410008
13. U1 Battery (2 needed)- LRA402208
14. Seat Bracket- LRC402414
Seat Slides- LRA402317



15. Battery Charger- LRA402209
16. Anti-tipper Wheel- LRB302311
17. Charger Port Gen 1- LRA402210-02
Gen 2- LRA402210-03
18. Circuit Breaker- LRA402207
19. Tiller Steering Stem- LRB402300-23

20. Lower Folding Hinge- LRB402341
21. Tiller Bearing Set- LRB402341
22. Seat Post- LRC402414-23
23. Hub Cap Black Wheel- LRM412103-11
24. Tiller Assembly- LRB402300-02

[1] When stock is gone the part will be no longer available.

01/