


# SPITFIRE 1410



Parts are no longer available except what is listed below.

1. Control Panel Assy.- LRM414100

2. Control Panel Decoration  
Blue- LRM412103-03B

3. Lower Control Panel Cover- LRM412101-15

4. Battery Gauge- LRM412103-05

5. Speed Dial Assembly- LRM412103-10

8. PC Board- LRM302104

9. Seat Assembly- LRM302116-02

Back Cover- LRM302213-08

Seat Cover- LRM302213-09

10. Armrest Pad- LRM302115-01

11. Basket- LRA402226

16. Armrest Locking Knob- S31052

17. Battery (2 needed)- LRM402109

Battery Box & Batteries- LRM302108

18. 20 amp Circuit Breaker- LRM302107

Substitute- LRM302207

19. Anti-tipper Wheel- LRM302114

20. Controller- LRM412105

Speed Dial Knob- LRM412103-11  
6. Key Switch- LRB402323-02  
Key- LRB402323-01  
7. Horn Assembly- LRM412103-08

Basket Liner- LRA402206-FBL  
12. Basket Bracket- LRM412101-08  
13. Seat Post Pin- LRM302200-28  
14. Tiller Adjustment Knob- LRA402201-23  
15. Tiller Bearing Set-LRB402348

21. Gearbox Only- LRM412106-01  
22. Battery Charger- LRM302111  
23. Front Wheel Bearings (pr)- S350100-B  
24. Hub Cap- LRM412202-HC  
25. Front Shroud Blue- LRM402118-B [1]

[1] When stock is gone the part is no longer available.

**02/26/2021**

[Diagrams](#)

[Home](#)