

ZOOME AUTO FLEX



1. Controller- FLEX-29

2. Throttle Pot- FLEX-AUTO-01

2. Throttle Pot Assembly- FLEX-AUTO-02

Throttle Lever- FLEX-AUTO-03

3. On-Off Switch- FLEX-AUTO-05

4. Speed Pot- FLEX-AUTO-06

5. Horn Button- FLEX-AUTO-07

Horn- FLEX-AUTO-04

6. Junction Board- FLEX-AUTO-08

Junction Board- FLEX-AUTO-08N [2]

7. Battery Gauge- FLEX-AUTO-09

8. Upper Console Blue- FLEX-AUTO-10

Upper Console Red- FLEX-AUTO-10R

9. Lower Console Blue- FLEX-AUTO-11

Lower Console Red- FLEX-AUTO-11R

10. Quick Release Clamp- FLEX-AUTO-12

11. Handle Connector- FLEX-AUTO-13

12. Steering Knuckle, Left- FLEX-AUTO-14

Steering Knuckle, Right- FLEX-AUTO-15

Steering Knuckle Bearing- FLEX-11

13. Footboard Blue- FLEX-AUTO-16

Footboard Red- FLEX-AUTO-16R

14. Floor Mat- FLEX-AUTO-17

15. Folding Actuator Assembly- FLEX-AUTO-18

Folding Actuator Assy- FLEX-AUTO-51 [1]

Folding Actuator Assy- FLEX-AUTO-51-2.4 [5]

16. Wireless Receiver- FLEX-AUTO-19

Wireless Receiver- FLEX-AUTO-50 [1]

Wireless Receiver- FLEX-AUTO-50N [2]

Wireless Receiver- FLEX-AUTO-50-2.4 [5]

17. Key- FLEX-AUTO-20

Wireless Remote Key- FLEX-AUTO-21

Wireless Remote Key- FLEX-AUTO-21-2.4 [5]

18. Armrest Assembly, Left- FLEX-AUTO-23

Armrest Assembly, Right- FLEX-AUTO-24

Arm Pad- FLEX-37

19. Armrest Knob- FLEX-AUTO-25

20. Charger Port- FLEX-AUTO-26

21. Actuator Switch- FLEX-AUTO-27

Actuator Switch- FLEX-AUTO-27N [8]

Actuator Switch- FLEX-AUTO-27-2.4 [5]
22. Reverse Horn- FLEX-AUTO-28

23. Rear Shroud Blue- FLEX-AUTO-29

Rear Shroud Red- FLEX-AUTO-29R

Rear Shroud Decor Blue- FLEX-AUTO-30

Rear Shroud Decor Red- FLEX-AUTO-30R

24. Anti-Tipper Wheel- FLEX-AUTO-31

25. Main Harness- FLEX-AUTO-45

Main Harness- FLEX-AUTO-45N [2]

Main Harness- FLEX-AUTO-45-2.4 [5]

26. Front Cover- FLEX-12

27. Gas Spring Assembly- FLEX-AUTO-34

28. Front Reflector Assy Blue- FLEX-AUTO-39

Front Reflector Assy Red- FLEX-AUTO-39R

29. Front Wheel- FLEX-07

30. Release Cable- FLEX-AUTO-46

31. Release Lever- FLEX-21

32. Battery Pack- [3] [6]

Battery Pack- FLEX-AUTO-47 [4]

Battery Case Only- FLEX-AUTO-48 [4] [7]

Battery Contacts (4 ea)- FLEX-31

33. Rear Wheel- FLEX-25

34. Battery Charger- FLEX-27

35. Motor/Brake/Transaxle Assy- FLEX-AUTO-44

Transaxle- FLEX-51

Motor- FLEX-52

Brake- FLEX-AUTO-43

36. Seat Complete- FLEX-AUTO-37

Back Upholstery- FLEX-AUTO-36

Seat Upholstery- FLEX-AUTO-35

37. Tie Rod Complete- FLEX-13

38. Hub Cap- FLEX-10

39. Wheel/Stem Bearing- FLEX-11

40. Armrest Receiver, Left- FLEX-AUTO-32

Armrest Receiver, Right- FLEX-AUTO-33

41. Folding Latch Assy Yellow- FLEX-AUTO-38

Folding Latch Assy Red- FLEX-AUTO-49 [1]

not shown Ext Charging Station- FLEX-50

not shown Basket Only- FLEX-AUTO-40

not shown Basket mount- FLEX-AUTO-41

not shown Cup Holder- FLEX-AUTO-42

[1] Serial # (21)24S1803000001 to (21)24S1909000001

[2] Serial # (21) 24S1909000001 and higher

[3] Lower than Serial # (21)24S1712000001

[4] Serial # (21)24S1712000001 & higher

[5] Serial #(21)24S2112000001 & higher

[6] No longer available.

[7] When stock is gone the part is no longer available.

[8] Serial #24S1803000001 to (21)24S2112000001