


Only parts listed below are available.

1. Seat rail guide -STDS1090
2. Handgrip -TRHG
3. a desk length arm pad -STDSDSKNB
full length arm pad -STDSFLNB
b. arm pad bolts -STDS002001
- c. arm rest panel Chrome -STDS002044
arm rest panel Black -STDS002045
arm rest panel Plastic -STDS2A4203 right -04 left
- d. arm release button -STDS002045
4. Back upholstery screw (8 ea)- STDS5D5504
5. Seat upholstery screw (8 ea)- STDS1072-8
6. Brake, push to lock Right -STDS4015R
Left -STDS4015L
7. Rubber brake tip -STDS4011
8. Seat saddle -STDS4058
9. Frame plug -STDS000005
10. Fork stem dust cap -STDS1051
11. Caster stem bearings -STDS1060
12. Caster fork -STDS3003
a. Fork stem lock nut -STDS001045
13. Caster bearings -STDS1011
14. Front axle bolt -STDS1002-1
15. Caster -STDS1002
16. Rear axle dust cap -STDS1000C
17. Handrail screws and spacers a. STDS1073
b. **No longer Available**
18. Rear wheel -with Blk handrail -STDS1006
with Chrome handrail -STDS1000
with Aluminum handrail -STDS1001
Black handrail -STDS004012
Chrome handrail -STDS004010
Aluminum handrail -STDS004011
19. Rear wheel bearings -STDS1012
20. Rear axle bolt -STDS1005
21. Footrest release lever -STDS00004R (right)
-STDS00004L (left)
22. Footrest adjustment bolt -STDS001051
23. Footrest bumper -STDS1026
24. Foot plate -plastic -STDS4S0906-1
25. Heel strap post -STDS1M4047
26. Heel strap pair -STDS831



04/15/2021

[Diagrams](#)

[Home](#)