


FAULT CODE CHART

WS-1 CONTROLLER

**SPEED INDICATOR ON
JOYSTICK** 



LOW BATTERY



COMMUNICATION ERROR



CHARGER IS PLUGGED IN



**DISPLACED JOYSTICK WHEN UNIT IS
TURNED ON**



MOTORS ARE IN FREEWHEEL MODE

[Home](#)