

795 (DUET) FLUTTER ELIMINATION

1. Loosen the Allen screw.



2. Tighten the bolt slightly. Try the rollator, if the flutter still exists, tighten slightly again.



3. When the flutter is gone tighten the Allen screw.





[Home](#)