

11114 - 11114KD



Casters can be placed in any location.

- 1. Back Assembly- 11114-BA**
- 2. Arm Pad- 11114A**
- 3. Seat with Frame**
 - Non-KD- 11114SEAT**
 - KD- 11114KD-PSS**
- 4. Bucket- 11108-1**
- 5. Locking Caster- 11114CL-G**
- 6. Non-Locking Caster- 11114C-G**
- 7. Lower Frame Base- 11114LFB***
 - *No longer used.**

Dimension Diagram

[Diagrams](#)

[Home](#)