



— HAND PENDANT CONTROL  
SP01-72298

1. PRESS THE BED DOWN  
BUTTON...
2. THEN PRESS THE BED UP  
BUTTON AND KEEP THEM  
BOTH PRESSED IN.
3. THE BED WILL LOWER,  
LEVEL OUT AND BEEP.