


BARIATRIC ALUMINUM TRANSPORT CHAIR (ATC22-R)



- | | |
|------------------------------------|--|
| 1. Arm Pad- STDSFLNB | 15. Wheel Lock Assembly Left - STDS2A5409 |
| 2. Handgrip- STDS871 | Wheel Lock Assembly Right- STDS2A5410 |
| 3. Hanger Pins (4 ea)- STDS1069-4 | Wheel Lock Tips (2 ea)- STDS2A5411 |
| 4. Caster- STDS1075 | 16. Slide Tube & Bushing- STDS2A5413 |
| 5. Axle Cap- STDS001000 | 17. Seat Upholstery- STDS2A5414 |
| 6. Caster Bearing- STDS1011 | 18. Hand Brake & Cable Left- STDS2A5415 |
| 7. Fork- STDS3045-2 | Hand Brake & Cable Left- STDS5D5415 [1] |
| 8. Fork Stem Bearing- STDS1060 | Hand Brake & Cable Right- STDS2A5416 |
| 9. Dust Cap- STDS1051 | Hand Brake & Cable Right- STDS5D5416 [1] |
| 10. Back Upholstery- STDS2A5400 | 19. Footrest (pr)- STDS2A5417 |
| Back Upholstery- STDS5D5400 [1] | 20. Back Uphol. Hardware (8 ea)- STDS2A5418 |
| 11. Seat Belt- STDS850-PB | 21. Seat Uphol. Hardware (10 ea)- STDS2A5419 |
| 12. Folding Back Hinge- STDS2A5403 | 22. Rear Wheel- STDS2A5420 |
| 13. Spreader Bar- STDS2A5404 | 23. Rear Wheel Bearing (pr)- STDS2A5421 |
| Spreader Bar Knob- STDS2A5405 | 24. Hub Cap- STDS2A5422 |
| 14. Anti-Tippers (pr)- STDS2A5408 | 25. Rear Axle- STDS2A5423 |
| | 26. Caster Axle- STDS2A5424 |

[1] 5D serial number only.